GENERAL

aisc steel design guide 25 tapered beams

Published: September 19, 2026 | Index ID: #-

Introduction

When it comes to modern structural engineering, the AISC (American Institute of Steel Construction) provides the most widely recognized standards and guidance for designing steel members. Among the many resources available, the **AISC Steel Design Guide 25 – Tapered Beams** stands out as a definitive reference for engineers who need to analyze, size, and construct tapered steel beams that meet safety, performance, and cost efficiency goals. This guide fills a critical gap by offering a systematic approach to the design of beams whose cross section varies along their length, a scenario that arises frequently in high rise buildings, bridges, and industrial structures where material savings and structural optimization are paramount.

In this comprehensive article, we'll walk through the core concepts, practical steps, and best practices for using the AISC Steel Design Guide 25. Whether you're a seasoned structural engineer, a graduate student, or an architect collaborating with a design team, you'll find clear explanations, illustrative examples, and actionable insights that will help you apply tapered beam design effectively in your projects.

Understanding Tapered Beams in Structural Design

What Is a Tapered Beam?

A tapered beam is a structural member whose cross section changes gradually along its span. Unlike a conventional rectangular or I beam, where the flange and web dimensions remain constant, a tapered beam's flange width, web thickness, or overall depth can vary, typically to match the load distribution or to reduce material usage.

Common applications include:

- High rise floor slabs that require deeper beams near the center and shallower beams near the supports.
- Bridge decks where load intensity decreases towards the ends.
- Industrial platforms that need to accommodate variable equipment loads.

Why Use Tapered Beams?

The advantages of tapered beams are manifold:

1. Material Efficiency: By aligning the beam's section size with the bending moment distribution, you can significantly reduce steel consumption.
2. Cost Savings: Less material translates to lower purchase and transportation costs.
3. Performance Optimization: Tapered beams can provide higher strength where needed, improving overall structural performance.
4. Architectural Flexibility: They allow for slimmer profiles that free up space and enhance aesthetics.

The AISC Steel Design Guide 25: An Overview

The AISC Steel Design Guide 25, officially titled "Tapered Beams," was developed to address the lack of standardized procedures for designing beams whose cross section varies along the span. Published by AISC, the guide provides:

- A step by step methodology for determining the optimal taper shape.
- Formulas for calculating internal forces, deflection, and buckling resistance.
- Tables and charts for quick reference.
- Case studies demonstrating real world applications.

While the guide builds on the fundamental principles found in the AISC Steel Construction Manual (SCM), it introduces additional concepts such as variable moment of inertia and the effect of taper on shear flow. By following the guide, engineers can design tapered beams that are compliant with AISC 360 – the main structural steel code in the United States.

Key Design Considerations for Tapered Beams

Load Types and Distribution

Understanding the loading conditions is the first step in any beam design. Tapered beams respond differently to:

- Uniformly Distributed Loads (UDL): Common in floor slabs, where the load is spread evenly.
- Point Loads: Typical of equipment or concentrated live loads.
- Variable Loads: Such as those found in bridges where traffic patterns vary along the span.
- Temperature Effects: Differential expansion can cause additional stresses.

Material Selection

The guide assumes the use of structural steel grades defined in AISC 360, such as S235, S275, and S355. Key material properties include:

- Yield strength (Fy)
- Ultimate strength (Fu)
- Modulus of elasticity (E)
- Density and cost per unit weight

Choosing the appropriate grade balances strength, ductility, and cost, especially when the beam's cross section varies.

Section Properties and Geometry

Tapered beams are defined by their varying section modulus (Z) and moment of inertia (I) along the span. The AISC guide recommends using a linear or quadratic taper function, depending on the load profile. The following parameters are critical:

- Depth (d): The vertical dimension of the section.
- Flange Width (b): The horizontal dimension of the top and bottom flanges.
- Web Thickness (tw): The vertical thickness of the web.
- Flange Thickness (tf): The horizontal thickness of the flanges.
- Section Modulus (Z): Used for bending calculations.
- Moment of Inertia (I): Used for deflection calculations.

Code Compliance and Safety Factors

All designs must comply with AISC 360, which prescribes partial safety factors for materials, loads, and dimensions. The guide also highlights:

- Use of the partial safety factor for yield strength (;4Ó ’ æB VÇF–Ö FR 7G&VæwF, ƒ³M1).
- Verification against deflection limits (typically L/240 or L/360 for floor slabs).
- Checks for shear buckling and local buckling of the web.

- Consideration of connection design and the effect of taper on bolt spacing.

Design Process: Step by Step Using Guide 25

Step 1: Define the Span and Loading Conditions

Start by determining the beam's effective span length (L) and the type of loads it will carry. Identify the maximum bending moment (Mmax) and shear force (Vmax) for the span. Use the AISC loading tables if the load distribution is standard.

Step 2: Select an Initial Taper Function

Choose between linear and quadratic tapering. A linear taper is often sufficient for simple UDLs, while a quadratic taper may better match the bending moment curve for variable loads.

Example linear taper formula:

\\nb(x) = b0 + (bL - b0) * (x / L)\\n\\nwhere *b0* is the flange width at the support, *bL* at the free end, and *x*the distance from the support.

Step 3: Calculate Section Properties Along the Span

For each section along the beam, compute:

- Section modulus, Z(x) = (b(x) * d(x)²) / 6 for a rectangular section.
- Moment of inertia, I(x) = (b(x) * d(x)³) / 12.
- Shear area, As(x) = b(x) * tw(x).

These calculations can be automated using spreadsheet or CAD software.

Step 4: Check Bending Capacity

Verify that the design bending stress does not exceed the allowable stress:

\\n<6"‡,• = M(x) / Z(x) "d Fy / ;4Ó ÅÆåÅÆåW6P the maximum moment at each section and compare it with the section modulus.

Step 5: Verify Shear Capacity

Check that the shear stress is below the allowable shear strength:

\\n<Gb‡,' Ò V(x) / As(x) "d <F ÆÆðw\\n\\nwhere <F ÆÆðw is typically 0.6 * Fy / ;4Ó `or steel.

Step 6: Deflection Analysis

Compute the deflection using the integration method for variable I:

\\n;@ = "+ € 8 [M(x) * (L - x) / (E * I(x))] dx\\n\\nEnsure that the maximum deflection does not exceed L/240 for floors or L/360 for other applications.

Step 7: Check for Buckling

Verify that the web and flanges are not susceptible to local buckling. Use the AISC buckling formulas, adjusting the effective width for tapered sections.

Step 8: Connection Design

Connections must accommodate the varying cross section. Ensure that bolt spacing and plate thickness are adequate for the maximum shear and bending moments at each location.

Step 9: Iterate and Optimize

After initial checks, adjust the taper function to reduce material usage while maintaining safety. Small changes in flange width or web thickness can yield significant savings.

Practical Example: Designing a 25 Foot Tapered Beam

Project Parameters

- Span length: 25 ft (7.62 m)
- Uniformly distributed load: 4 kips/ft (17.6 kN/m)
- Maximum bending moment: Mmax = wL²/8 = 4 * 25² / 8 = 312.5 kip ft
- Maximum shear: Vmax = wL/2 = 4 * 25 / 2 = 50 kip

Choosing a Taper

For a UDL, a linear taper is adequate. Let the flange width at the support be 12 in and at the center 8 in. The depth remains constant at 16 in.

Section Property Calculation

At the support (x = 0):

- b0 = 12 in
- Z0 = (12 * 16²) / 6 = 512 in³
- I0 = (12 * 16³) / 12 = 2048 in t

At the center (x = 12.5 ft):

- bL = 8 in
- ZL = (8 * 16²) / 6 = 341 in³
- IL = (8 * 16³) / 12 = 1365 in t

Bending Check

Using AISC S275 steel (Fy = 275 ksi, ;4Ó Ò ã#R“

- Allowable stress = 275 / 1.25 = 220 ksi
- Design stress at support: <6# Ò 3 "ãR ¶— gB ò S " –ë2 Ò 3 "ãR ¢ " ò S " $, rã3" ·6•
- Design stress at center: <6$Â Ò 3 "ãR ¢ " ò 3C $, ã“’ ·6•

Both stresses are well below 220 ksi, indicating adequate bending capacity.

Shear Check

Assuming web thickness tw = 0.5 in:

Baca Juga (Artikel Terkait)

- **advanced engineering electromagnetics solution manual edition hardcover by balanis constantine a published by wiley**
  URL: http://denniswildberger.com/advanced-engineering-electromagnetics-solution-manual-edition-hardcover-by-balanis-constantine-a-published-by-wiley.pdf
- **advanced engineering electromagnetics solutions manual**
  URL: http://denniswildberger.com/advanced-engineering-electromagnetics-solutions-manual.pdf
- **advanced engineering electromagnetics wiley 1989 grading**
  URL: http://denniswildberger.com/advanced-engineering-electromagnetics-wiley-1989-grading.pdf

- **advanced engineering fluid mechanics by biswas**

  URL: http://denniswildberger.com/advanced-engineering-fluid-mechanics-by-biswas.pdf

Tags: #aisc #steel #design